


Profile Drawing



Profile Dimensions

Profile (mm)	Thickness (mm)	Length (m)	Overall width (mm)	Cover Width (mm)	Side-Lap (%)
76 / 18	1.0	1.5 - 11.8	1190	1140	4.2


Load / Span Data

Load (kg/m ²)	Maximum Roof Span (mm)
	1.0 mm
50	1100
75	1000
100	900
125	800
150	700

- The specified dimensions do not supersede the requirements of local construction codes.
- The maximum purlin spans are based on continuous beam calculation model and practical testing.
- The criterion for allowed deflections is L/20.
- The mentioned load refers to both wind and snow loads.
- Minimum recommended slope – 10%.
- For vertical applications spans can be increased by 10%.

Panel Length

- Maximum recommended panel length - 7.0 m.
- Recommended longitude overlaps of 200mm above purlin.
- Each panel to extend 100mm over the fixings line on the purlin.
- Panels should overhang Min. 50mm and Max. 100mm beyond the last fixings line.



Curved Roof

- Minimum curving radius 4.0 m.



PALRUF® Technical Guide

Profile: GRECA 76



24/01/2019

Positioning

- Apply one corrugation side-lap. Two corrugations side-lap is recommended for low roof slope and/or high wind areas.
- Side-lap of PALRUF panels must be installed against the primary direction of rain.
- **Do not install PALRUF over existing roof or ceiling, without prior consultation with the manufacturer PALRAM.**
- For contact details please refer to PALRAM's official website at www.palram.com.
- The PALRUF panels must be located and installed without any stresses.
Do not pull, stretch or force the sheets when the profiles are not perfectly matched.




Fastening

- Apply sealing tape over the PALRUF panel side-lap corrugation crests, where covered by the next panel.
- Apply sealing tape along the bottom and top End-lap (if there is), along screws centerline or two tapes on both sides of screw centerline.
- Pre-drill 10mm holes at crests where screws are positioned.
- Start fastening the screws from the first side-lap (left) through the pre-drilled holes
- Start fastening the screws on the lower edge purlin (End-lap), through every other corrugation crest/Valley depending on installation type.
- Fasten screws at the internal purlins, through every third corrugation crest/valley, starting at the same side.
- Fasten screws at the upper edge purlin, through every other corrugation crest/valley, starting at the same side. When using Ridge-Cap or Top wall trim, place it before fastening the upper purlin screws.
- **Do not over-tighten!**
- Stitching screws: Fasten the at every 300-400 mm






Fastening Location

Crest Installation with crest support



Valley Installation



Screws and Washers Specification

Crest Fixing:


- Screws for metal purlins: Self-drilling 6.5mm (1/4") x 40mm (1 1/2") screw with 19mm washer and EPDM gasket.
- Screws for wooden purlins: Tapping 6.5mm (1/4") x 50mm (2") screw with 19mm washer and EPDM gasket.

Valley Fixing:

- Screws for metal purlins: Self-drilling 6.5mm (1/4") x 25mm (1") screw with 19mm washer and EPDM gasket.
- Screws for wooden purlins: Tapping 6.5mm (1/4") x 40mm (1 1/2") screw with 19mm washer and EPDM gasket.
- Washers: metal crest rider (Storm washers) with EPDM gasket or 25mm (3/4") PALRAM washers.
- Side Stitching: 6.5mm x 25mm (1/4"x1") self tapping screw with 19mm washer and EPDM gasket.











Accessories



Foamed polyethylene closure 988mm wide



Closure strip=Crest support 610mm wide

	Illustration	Cross Section	Dimensions mm (in.)
Universal Ridge Cap			2.280 x 270 x 270 (90 x 10 x 10)
Universal Ridge Cap			2.280 x 150 x 150 (90 x 6 x 6)
Top Wall Trim			2.280 x 50 x 150 (90 x 2 x 10)
Side Wall Trim			2.280 x 50 x 130 (90 x 2 x 5)

PALRUF® Technical Guide

Profile: GRECA 76



24/01/2019

Important Notes

- Use only PALRAM approved accessories, including EPDM rubber washers, silicones, sealing tape, closure fixtures etc.
- For clear PALRUF onto wooden purlins, apply white acrylic paint, or aluminum tape, in order to prevent over-heating of the purlins.



Cutting Tips

- Use jigsaw or circular saw with fine tooth blades.
- Apply high blade speed with moderate feeding rate.
- Support the sheets near the cutting line.
- Clean the dust and cutting chips after cutting.



Fastening Tips

- Use adjustable electric screwdriver.
- The screw must be installed perpendicular to the PALRUF sheet.
- **Important: Do not over-tighten.**




Safety

- Do not step directly on the panel.
- Use stepping boards.
- Work according to local safety regulations.



Handling and Storage

- Store in a shaded place, protect from direct sunlight and rain.
- Cover PALRUF stack with white opaque covering.
- Avoid covering the sheets with heat absorbing materials.
- Avoid contact or environment of chemicals.
- Protect the sheets from any physical damage.
- After installation keep sheets free of dust and suit.
- Sheets should be cleaned frequently with a water hose.



Inasmuch as PALRAM Industries has no control over the use to which others may put the material, it does not guarantee that the same results as those described herein will be obtained. Each user of the material should make his own tests to determine the material's suitability for his own particular use. Statements concerning possible or suggested uses of the materials described herein are not to be construed as constituting a license under any PALRAM Industries patent covering such use or as recommendations for use of such materials in the infringement of any patent. PALRAM Industries or its distributors cannot be held responsible for any losses incurred through incorrect installation of the material. In accordance with our company policy of continual product development you are advised to check with your local PALRAM Industries supplier to ensure that you have obtained the most up to date information.